


SKU # 1001 358 758 YOW SKU # 693 299 Model # TY496-1514

USE AND CARE GUIDE

36 in Lighted Burlap Owl Wreath



THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 36 in Lighted Burlap Owl Wreath. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

Guarantee

What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday


1-877-527-0313 HOMEACCENTSHOLIDAY.COM


Pre-Assembly

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

PACKAGE CONTENTS







Package Contents/Parts List	
Description	Quantity
Arcs of Wreath	4
Head of Owl	1
Body of Owl	1
Spare Fuse	1
Spare Bulb	4
Plastic Ties	10
Accessory Bow	1
	Description Arcs of Wreath Head of Owl Body of Owl Spare Fuse Spare Bulb Plastic Ties

Assembly

Assembling the Burlap Owl with Wreath



Step1. Insert the metal rod at each Arc of Wreath (A) into the corresponding hole in the adjacent arc then fasten them together with Plastic Ties using the metal rings on the frame (F). (FIG.1)



Step 2. Insert the rods of the Head of Owl (B) into the matching holes on the Body of Owl (C). (FIG.2)

Step 3. Insert the rods at the bottom of the Owl into the matching holes on the assembled Wreath. (FIG.2)

Step 4. Insert the wires of the Accessory Bow (G) through the holes of the wreath then twist the wires together to secure.

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 40.8 Watts (0.34Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

- a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
- b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
- c. Store the product neatly in a cool, dry location protected from sunlight.

FOR INDOOR AND OUTDOOR USE